

## The RainWise® Wired Rain Gauges

### RAINEW 111 Tipping Bucket Wired Rain Gauge

The 8" diameter collector meets NWS specifications for statistical accuracy. Every time the bucket tips, a count is transmitted to the indoor display and the gauge empties. You never have to empty the gauge. Each tip of the bucket shows one hundredth of an inch on the indoor LCD display. The display will indicate up to 9.99" of rain. A button on the counter lets you reset to zero after each rainfall. Installation to the plug-in counter is a cinch. The long-life alkaline counter battery is included. Mount this gauge out in your yard and record rainfall inside the house.

- Self emptying
- 60 feet of cable included
- Lifetime collector warranty



### RAINEW 211 Tipping Bucket Dual Counter Wired Rain Gauge

The 8" diameter collector meets NWS specifications for statistical accuracy. Every time the bucket tips, a count is transmitted to the indoor display and the gauge empties. You never have to empty the gauge. Each tip of the bucket shows one hundredth of an inch on the indoor LCD display. Installation to the plug-in counter is a cinch. Mount this gauge out in your yard and record rainfall inside the house.

- Redesigned for Spring 2007
- Self emptying.
- Dual Displays.
- Lifetime collector warranty

The dual displays allow you to track both individual events and keep an annual running total. The dual counter requires 3 "AA" alkaline batteries and two button cell batteries. The button cell batteries are included and will last for several years.

